




Simulation Only -
Use computer_programming.bdf
when flashing to your DE10-Lite




Memory Map

EPROM Range = \$0000 to \$0FFF (read only)
SRAM Range = \$1000 to \$1FFF (read/write)

External Memory



File=eprom.mif



File=sram.mif

